



#### MEASURING for ANGLE BUILD OUT

- \* (1) Measure your net opening in 3 places (top, middle & bottom), more if desired
- \* (2) Take the smallest measurement & subtract 0.75". This measurement is the Overall Width (OAW) of your screen.
- \*NOTE: Angle Build Out can be used to correct out of true wall up to 1.5".

#### ANGLE BUILD-OUT INSTALLATION

USE: on recess fit installations where the side walls are not level & parallel. Example, the patio inside width is 125" at the top but only 124" at the bottom.

- \*1 Install Angle Build Out BASE to side walls flush to the wall. Base will be provided @ OAH of the screen.
- \*2 Attach rails (& screen if required) to Angle Build Out.
  - (A) Center rails where desired on the Angle
  - (B) Level & square rails on the Angle
  - (C) Pre drill screw holes w 5/32" drill bit
  - (D) Attach rails & back housing to Angle with #10 x ¼ blunt head screws (provided)
- \*3 Complete screen installation
- \*4 Install Angle Build Out COVER (provided at rail height). Pre-drill with 7/64<sup>th</sup> drill bit, countersink & install #6 x 3/8<sup>th</sup> flathead screws (provided)

NOTE: On your order, mark Build out as RECESS DRILLED & the Solution Rails as SURFACE DRILLED.